
A step-by-step guide to creating an app


1. Go to https://appinventor.mit.edu/




2. Click on "Create Apps" and then choose "Start a new project"




3. After clicking "Start a new project", you should see the following page.




4. From "User interface", drag and drop "ListPicker" on the screen




5. Edit the properties from the "Properties" tab on the right-hand side. Change color to green, width to "fill parent" and text to "Connect".




6. From Layout drag and drop "TableArrangement" to screen. Edit properties from the right-hand side tab. Change column to 3, rows to 3, and width to "fill parent"



7. From the user interface drag and drop 7 buttons to the screen.




8. Drag and drop a 'button' from the screen to the 'TableArrangement'. And edit the property of the button. Width to "32 %", height to "20%", Text to "A", and color to your choice.




9. From "Connectivity" drag and drop "Bluetoothclient1". You can see that at bottom of the phone.




10. From "sensors" drag and drop "clock". You can see that at bottom of the phone.




11. Do step 8 for all buttons. You should get results similar to the below-shown image.




12. Click on "blocks" in the top-right corner.





13. Choose "ListPicker1". Drag and drop "when ListPicker1.BeforePicking".





14. Now, drag and drop code blocks as shown in images.

























Do the above step for all the buttons and the final result should be as below.



15. After completing the above steps, click "Designer" on the top-right corner. From the dropdown menu of "Build" click on "Android app (apk)".



16. After clicking, the app will start compiling, and after completion of compilation, you should see the option to download the app or download by scanning the QR code. Choose your preferred option.

